

FIGURE 8-21A
BOX END HOPPER
ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY.
1	00179XX	BAR, GUIDE SUPPORT	REF
2	0013102R/L	RAIL, END HOPPER (INSIDE)	1/1
3	0013302R/L	RAIL, END HOPPER (OUTSIDE)	1/1
4	0013202R/L	MT. BRACKET, END HOPPER	1/1
5	0057700	GUIDE, MOUNT	2
6	0057600	ADJUSTING CLAMP	2
7	0057500	GUIDE, MOUNT BRACKET	2
8	0057400R/L	GUIDE, HOPPER	1/1
9	0034200	BAR, HEAD GUIDE MT	4
10	0013401R/L	UPPER HOPPER GATE	1/1
11	0020800	ROD, END HOPPER SPREAD	2
12	0037700	SUPPORT, LG BLISS END HOPPER	2
13	0037600	BRACE, BLISS LONG END HOPPER	2
14	0029600	MOUNT, END HOPPER SUPPORT	2
15	0100400	SET COLLAR	2
16	0057802R/L	RETAINER, BOX END	1/1
17	0022900	SHIM, 16 GA.	4
18	0029300	SHIM, 1/4"	4
19	0025901	DEFLECTOR, MATT	2
20	0204300	BUSHING	2
21	0022401	ROLLER, END HOPPER	2
22	0013403R/L	GUIDE-BOX END	1/1




FIGURE 8-21A
BOX END HOPPER
ASSEMBLY

FIGURE 8-21B
BOX END HOPPER
PUSHER ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY.
1	0026608	RAIL	2
2	0037804	SIDE HOPPER SLIDE BAR	1L/1R
*	0037807	SIDE HOPPER SLIDE BAR (EXT.)	1L/1R
3	0037805	HORIZONTAL SHAFT	4
4	0044804	BOTTOM STOPPER	1L/1R
5	0044803	TOP STOPPER	2
6	0037806	PUSHER	4
7	2126800	SET COLLAR, TENSION ADJ.	2
8	1200100	SPRING	2L/2R
9	0013302	RAIL-HOPPER	REF
10	0044802	RAIL STOPPER	4
11	0013303	SPACER	2L/2R
12	0013304	SPACER	2
13	0026503	ROLLER	2
14	0204400	BUSHING	2
15	0201700	BUSHING	2
16	1501100	WASHER	2
17	0044801	RAIL BOTTOM STOPPER	2
18	0037808	SIDE HOPPER WEIGHT	2
19	00378103	BAR ROLLER	2
20	0042801	AXLE-DOUBLE WEIGHT	2
21	0042701	LEVER	1L/1R
22	0072700	KNOB, LEVER	2
100	8008800	5/16 NC X 2 1/4 LG HEX HED	4
101	8036700	5/16 SPLIT LOCK WASHER	4




FIGURE 8-21B
BOX END HOPPER
PUSHER ASSEMBLY